


Similarly, the graph in Fig. 6.2 for cooking oil should scale down along the Q -axis.

7

Diagram:



Aim: To determine the value of n from the gradient of the graph of $\lg f$ against $\lg \mu$.

Independent variable: μ , mass per unit length of the wire.

The length L of the wire can be measured by using a metre rule and its mass m can be determined using the weighing balance. Hence, μ

can be calculated using $\mu = \frac{m}{L}$.

Dependent variable: f , frequency of the mode of vibration of the wire.

The frequency can be recorded from the signal generator.

Control variables:

- same length of wire, measured using metre rule
- same tension in the wire, by ensuring same weights hung
- same mode of vibration, by adjusting the frequency until the 1st overtone is observed (Fig. 7.1).

Procedure:

- Measure and record down the mass m of a wire of fixed length L (about 0.80 m) using the weighing balance.
- Set up the apparatus as shown in the diagram by attaching the wire to the fixed weights.
- Increase the frequency f of the signal generator from zero until a standing wave (1st overtone) is observed. measure using a light gates connected to a data logger to the frequency f shown on the on signal generator in the table.
- Adjust the frequency of the oscillator back to zero and repeat the experiment to obtain 3 values of f . Calculate the average value of frequency, $f_{average}$.
- Replace the wire with another one of different mass but same length L . Conduct the experiment from steps (a) to (d) for at least 6 different wires.
- Calculate the values of mass per unit length μ , where $\mu = \frac{m}{L}$ for each of the 6 wires used.
- On the same table, calculate the values of $\lg \mu$ and $\lg f$.
- Plot a graph of $\lg f$ against $\lg \mu$. Determine the value of n form the gradient of the graph since $\lg f = n \lg \mu + \lg k$.

Precaution: Ensure that the length of the wires used is the same throughout and the length between the pulley and oscillator is the same throughout.

Safety: Clamp the oscillator to the bench using a g-clamp. Also, avoid standing too close to the set-up while adjusting the frequency as the wire might dislodge from the oscillator.